
## How can I configure My Modem (Our Modems)

- Technicolor v1-Thomson:
- Connect to the Wi-Fi network of your modem.
- o Open any browser, and enter the gateway address (the default one is 192.168.1.254)
- o Click on Technicolor or Thomson Gateway → Setup my Thomson-Technicolor gateway



- Click Next
- Select a service : routed PPP



o VPI/VCI: 0/35 (Ogero), 8/35 (GDS), connections type: routed PPP over Ethernet



o Internet account setting: username X123456@idm.net.lb / password : XXXXXX



- o Access control: skip or any credentials you want
- Start
- o Finish.