Dlink DSL-2730U

- Establish a connection between the device and the router via network cable or Wi-Fi
- Open a browser and type 192.168.1.1 in the address bar
- You will be prompted to enter Username: admin and Password: admin



- After logging in, Device Info page will be displayed.



- Expand Wireless then click Basic and make sure wireless is enabled
- In SSID textbox type new Wireless Name then click Apply/Save



- Under Wireless , click Security
- Under Manual Setup AP , select the predefined SSID and Make sure Network Authentication is WPA-Personal or WPA2-pesonal
- In WPA/WAPI Passphrase type new Wi-Fi Password and click Apply/Save (safest passwords are long and contain at least 8 digits of mixed letters, and numbers)


D-Link
Device Info
Advanced Setup
Wireless
Basic
Security
MAC Filter
Wireless Bridge
Advanced
Station Info
Diagnostics
Management
Wireless -- Security
This page allows you to configure security features of the wireless LAN interface.
You may setup configuration manually
OR
through WiFi Protcted Setup(WPS)
WPS Setup
Enable WPS
Disabled
Manual Setup AP
You can set the network authentication method, selecting data encryption,
specify whether a network key is required to authenticate to this wireless network and
Click "Apply/Save" when done.
Select SSID:
DLink
Network Authentication:
WPA-Personal
Auto
WPA/WAPI passphrase:
Click here to display
WPA Group Rekey Interval:
0
WPA/WAPI Encryption:
TKIP+AES
Apply/Save