

Dlink DSL-124

You can apply this procedure on computer, PlayStation, XBOX, Nintendo and any other gaming device

PlayStation 4

In order to solve your PS4 problem please follow the below steps

- **Step 1:** Firstly navigate to the settings menu on your PS4
- **Step 2:** Next select Network
- **Step 3:** You need to select “set up internet connection”
- **Step 4:** You need to select “custom”
- **Step 5:** You need now to select the method in which your PS4 connects to the internet
- **Step 6:** Make sure to set your IP address manually
- **Step 7:** Enter the desired IP address that you would like to use for your PlayStation®4.
 - IP Address: 192.168.1.50
 - Subnet Mask: 255.255.255.0
 - Default Router: 192.168.1.1 (IP Address of your router)
 - Primary DNS: 193.227.177.130
 - Secondary DNS: 194.126.16.38
- **Step 8:** In MTU Settings, select automatic.
- **Step 9:** In Proxy servers , select Do Not Use
- **Step 10:** Select TEST Internet Connection.
- **Step 11:** Connect a device to your Dlink modem (using cable / WIFI)
- **Step 12:** In your browser enter the address 192.168.1.1
- **Step 13:** You will be prompted to enter Username: admin and Password: admin
- **Step 14:** Click Advanced then DMZ
- **Step 15:** Select correct WAN interface then type 192.168.1.50 in DMZ Host IP address
- **Step 16:** Click Apply changes

Product Page: DSL-124 Firmware Ver



DSL-124
SETUP
ADVANCED
MAINTENANCE
STATUS

Advanced Wireless

Access Control List

Port Triggering

Port Forwarding

DMZ

Parent Control

Filtering Options

DOS Settings

DNS

Dynamic DNS

Network Tools

Routing

NAT

DMZ

A Demilitarized Zone is used to provide Internet services without sacrificing unauthorized access to its local private network. Typically, the DMZ host contains devices accessible to Internet traffic, such as Web (HTTP) servers, FTP servers, SMTP (e-mail) servers and DNS servers.

DMZ CONFIGURATION

WAN Interface:

DMZ Host IP Address:

Apply Changes

CURRENT DMZ TABLE:

Select	WAN Interface	DMZ Ip
<input type="button" value="Delete Selected"/>		

- **Step 17:** Reboot your PS4 and your NAT type problem should be solved

PlayStation 3

In order to solve your PS3 problem please follow the below steps:

- **Step 1:** On your PS3: Go to network settings then Internet connection settings a
- **Step 2:** Choose the type of connection you are using (wired/wireless) then choose Manual IP and enter the following IP addresses:
 - IP Address: 192.168.1.50
 - Subnet Mask: 255.255.255.0
 - Default Router: 192.168.1.1
 - Primary DNS: 193.227.177.130
 - Secondary DNS: 194.126.16.38
- **Step 3:** Disable the UPnP and leave the rest of the setting as they are
- **Step 4:** Connect a device to your Dlink modem (using cable / WIFI)

- **Step 5:** In your browser enter the address 192.168.1.1
- **Step 6:** You will be prompted to enter Username: admin and Password: admin
- **Step 7:** Click Advanced then DMZ
- **Step 8:** Select correct WAN interface then type 192.168.1.50 in DMZ Host IP address
- **Step 9:** Click Apply changes

Product Page: DSL-124 Firmware Ver

D-Link

DSL-124 // **SETUP** **ADVANCED** MAINTENANCE STATUS

Advanced Wireless
Access Control List
Port Triggering
Port Forwarding
DMZ ← 2
Parent Control
Filtering Options
DOS Settings
DNS
Dynamic DNS
Network Tools
Routing
NAT

DMZ

A Demilitarized Zone is used to provide Internet services without sacrificing unauthorized access to its local private network. Typically, the DMZ host contains devices accessible to Internet traffic, such as Web (HTTP) servers, FTP servers, SMTP (e-mail) servers and DNS servers.

DMZ CONFIGURATION

WAN Interface: pppoe1
DMZ Host IP Address: 192.168.1.50 ← 3

Apply Changes Reset

CURRENT DMZ TABLE:

4 Select	WAN Interface	DMZ Ip
Delete Selected		

- **Step 10:** Reboot your PS3 and your NAT type problem should be solved

Laptop or Desktop

In order to solve your gaming problem on your computer please follow the below steps

- **Step 1:** Click Start then Control Panel
- **Step 2:** Click on network and internet then network and sharing center
- **Step 3:** When the Network and Sharing Center opens, click on Change adapter settings.
- **Step 4:** Right-click on your local or wireless adapter and select Properties
- **Step 5:** In the Local Area Connection Properties window double-click Internet Protocol Version 4 (TCP/IPv4)
- **Step 6:** Select use the following IP address and enter IPs and Subnet Mask

- IP Address: 192.168.1.50
- Subnet Mask: 255.255.255.0
- Default Router: 192.168.1.1 (IP Address of your router)
- **Step 7:** Then enter your Preferred and Alternate DNS server addresses
 - Primary DNS: 193.227.177.130
 - Secondary DNS: 194.126.16.38
- **Step 8:** Connect a device to your Dlink modem (using cable / WIFI)
- **Step 9:** In your browser enter the address 192.168.1.1
- **Step 10:** You will be prompted to enter Username: admin and Password: admin
- **Step 11:** Click Advanced then DMZ
- **Step 12:** Select correct WAN interface then type 192.168.1.50 in DMZ Host IP address
- **Step 13:** Click Apply changes

Product Page: DSL-124 Firmware Ver

D-Link

1

DSL-124 // **SETUP** **ADVANCED** MAINTENANCE STATUS

Advanced Wireless

Access Control List

Port Triggering

Port Forwarding

DMZ ← 2

Parent Control

Filtering Options

DOS Settings

DNS

Dynamic DNS

Network Tools

Routing

NAT

DMZ

A Demilitarized Zone is used to provide Internet services without sacrificing unauthorized access to its local private network. Typically, the DMZ host contains devices accessible to Internet traffic, such as Web (HTTP) servers, FTP servers, SMTP (e-mail) servers and DNS servers.

DMZ CONFIGURATION

WAN Interface: pppoe1

DMZ Host IP Address: 192.168.1.50

3

Apply Changes Reset

CURRENT DMZ TABLE:

	WAN Interface	DMZ Ip
4	Select	

Delete Selected

- **Step 14:** Reboot your computer to solve gaming problem.