


# Netis DL-Series

You can apply this procedure on computer, PlayStation, XBOX, Nintendo and any other gaming device

## PlayStation 4

In order to solve your PS4 problem please follow the below steps

- **Step 1:** Firstly navigate to the settings menu on your PS4
- **Step 2:** Next select Network
- **Step 3:** You need to select “set up internet connection”
- **Step 4:** You need to select “custom”
- **Step 5:** You need now to select the method in which your PS4 connects to the internet
- **Step 6:** Make sure to set your IP address manually
- **Step 7:** Enter the desired IP address that you would like to use for your PlayStation®4.
  - IP Address: 192.168.1.50
  - Subnet Mask: 255.255.255.0
  - Default Router: 192.168.1.1 (IP Address of your router)
  - Primary DNS: 193.227.177.130
  - Secondary DNS: 194.126.16.38
- **Step 8:** In MTU Settings, select automatic.
- **Step 9:** In Proxy servers , select Do Not Use
- **Step 10:** Select TEST Internet Connection.
- **Step 11:** Connect a device to your Netis modem (using cable / WIFI)
- **Step 12:** In your browser enter the address 192.168.1.1
- **Step 13:** You will be prompted to enter Username: guest and Password: guest
- **Step 14:** After logging in you have to click Advanced then expand NAT and click DMZ
- **Step 15:** Select Any WAN interface and type 192.168.1.50 in DMZ Host IP Address
- **Step 16:** Click Apply Changes




- **Step 17:** Reboot your PS4 and your NAT type problem should be solved

## PlayStation 3

In order to solve your PS3 problem please follow the below steps:

- **Step 1:** On your PS3: Go to network settings then Internet connection settings a
- **Step 2:** Choose the type of connection you are using (wired/wireless) then choose Manual IP and enter the following IP addresses:
  - IP Address: 192.168.1.50
  - Subnet Mask: 255.255.255.0
  - Default Router: 192.168.1.1
  - Primary DNS: 193.227.177.130
  - Secondary DNS: 194.126.16.38
- **Step 3:** Disable the UPnP and leave the rest of the setting as they are
- **Step 4:** Connect a device to your Netis modem (using cable / WIFI)
- **Step 5:** In your browser enter the address 192.168.1.1
- **Step 6:** You will be prompted to enter Username: guest and Password: guest
- **Step 7:** After logging in you have to click Advanced then expand NAT and click DMZ
- **Step 8:** Select Any WAN interface and type 192.168.1.50 in DMZ Host IP Address
- **Step 9:** Click Apply Changes



- **Step 10:** Reboot your PS3 and your NAT type problem should be solved

## Laptop or Desktop

In order to solve your gaming problem on your computer please follow the below steps

- **Step 1:** Click Start then Control Panel
- **Step 2:** Click on network and internet then network and sharing center
- **Step 3:** When the Network and Sharing Center opens, click on Change adapter settings.
- **Step 4:** Right-click on your local or wireless adapter and select Properties
- **Step 5:** In the Local Area Connection Properties window double-click Internet Protocol Version 4 (TCP/IPv4)
- **Step 6:** Select use the following IP address and enter IPs and Subnet Mask
  - IP Address: 192.168.1.50
  - Subnet Mask: 255.255.255.0
  - Default Router: 192.168.1.1 (IP Address of your router)
- **Step 7:** Then enter your Preferred and Alternate DNS server addresses
  - Primary DNS: 193.227.177.130
  - Secondary DNS: 194.126.16.38
- **Step 8:** Connect a device to your Netis modem (using cable / WIFI)
- **Step 9:** In your browser enter the address 192.168.1.1
- **Step 10:** You will be prompted to enter Username: guest and Password: guest
- **Step 11:** After logging in you have to click Advanced then expand NAT and click DMZ

- **Step 12:** Select Any WAN interface and type 192.168.1.50 in DMZ Host IP Address
- **Step 13:** Click Apply Changes

**LINKSYS™** Smart Wi-Fi App Center Help Sign Out

Status Quick Start Setup **Advanced** Service Firewall Maintenance

**DMZ**

A Demilitarized Zone is used to provide Internet services without sacrificing unauthorized access to its local private network. Typically, the DMZ host contains devices accessible to Internet traffic, such as Web (HTTP) servers, FTP servers, SMTP (e-mail) servers and DNS servers.

WAN Interface: any

DMZ Host IP Address: 192.168.1.50

Apply Changes Reset

Current DMZ Table:

Select	WAN Interface	DMZ Ip
--------	---------------	--------

Delete Selected

- **Step 14:** Reboot your computer to solve gaming problem.